

## Regular Fender Bag Installation Instructions

***Please read completely before installation!***

**Tools:** 2 large tip flat bladed screwdrivers, drill, 1/4" bit, Loctite Blue      **Time:** 5 to 10 minutes

- 1) Use the pattern on the back of this sheet to locate the mounting holes.

**center** of hole must be  
**on** or **within**  
**D-A-S-H-E-D**  
line

- 2) Drill 1/4" holes through your fender. Use a **properly sized** drill!
- 3) Cut an X shaped hole through the bottom of the fender bag to match the holes in the fender.
- 4) Mount the bag with the included hardware.
- 5) From top to bottom the proper order of the fasteners is:  
barrel nut – 1" washer – fender bag – bike fender – 3/4" washer – screw
- 6) **Use of a small amount of thread locker** such as Loctite Blue or a similar product. *Check the fit of the barrel nuts, washers and screws before applying the thread locker.*

### Notes

If the screws are too long or too short, you can find other lengths at any hardware store carrying SAE (American) hardware. The thread is 10-24. **Use the shortest screw that will do the job.** Flat headed screws like these are usually called **truss** screws. If you are located in Europe or other metric areas, you may need to buy all new metric hardware.

### Care of your fender bag

- When you get the fender bag very muddy, take a second and use your finger to wipe the mud off the zipper before opening. This will help to keep the zipper from derailing.
- You can certainly use a power washer on your bag if you like.
- No other care needed.

**REGULAR**

**center** of hole must be  
**on** or **within**  
**D-A-S-H-E-D**  
line